





Or code APP (APP二维码)

Need the apple version 9.0 and above, the android version 5.0 and above.

* This APP supports most of the mainstream Android madels on the market, but due to the large number of Android models, different, models of systems and hardware reasons, there may be some models do not support, specificacconding to the actual test!



广东宇星科技 Mould King



产品资讯
Product Information



售后服务 After-sales Service



积木补件

Brick Replacement Service





"酥砖家"是字星模王设立的特殊标识,代表着产品的独构性和原创性。每一款带有"醋砖东"标志的积木套装,都由字星的原创团队或者与字星有密切合作的全球顶尖设计师亲自设计或授权。这个标识是我们对消费者的承诺,确保他们可以享受到独一无二旦高品质的积木拼搭体验。

"Bri X pert" is a special mark established by MOULD KING, representing the uniqueness and originality of the product. Every building set with the "Bri X pert" logo is personally designed or authorized by MOULD KING's innovative team or world-class designers who work closely with MOULD KING. This logo is our commitment to consumers, ensuring that they can enjoy a unique and high-quality building experience.


OPEN








2



首先,旋开音乐盒底部的螺丝,取出电池外壳。 First, unscrew the bottom of the music box to remove the battery case. 请确保在指定位置正确安装两节7号电池。


Please ensure that two No. 7 batteries are correctly installed in the designated position.

3



K | \ 4

星模




安装好电池后,将电池外壳放回原位,旋紧螺丝。 After installing the batteries, put the battery case back in place and tighten the screw. 电池壳安装完毕后,将音乐盒的发条机构装上。

Once the battery case is installed, attach the wind-up mechanism of the music box.

顺时针旋转底座。音乐盒将开始播放音乐并自动旋转,带给您独一无 二的视听体验。

Rotate the base clockwise, the music box will start to play music and rotate automatically, providing you with a unique audiovisual experience.



6



取出灯带和灯珠,按照指示图的要求,将灯带和灯珠 的电线头插入,注意灯线头的正反面,确保按图示的 方向装入,否则灯光无法打开。

Remove the light strip and light beads. Following the instructions on the diagram, insert the connectors of the light strip and the light beads. Be sure to note the orientation of the light wire connectors. Ensure they are installed as shown in the diagram; otherwise, the lights will not turn on.





将插好的灯带沿着音乐盒底座的内壁绕一圈贴上, 灯珠的用途请看第241步骤。

Attach the connected light strip around the inner wall of the music box base. For the use of the LED bead, please refer to step 241.




8


(ING


灯光装好后,可通过开关进行操作。长按开关可以 开启或关闭灯光,短按则可以切换灯光模式(慢闪 或常亮)。


After the light is installed, it can be operated through the switch. Press and hold the switch to turn the light on or off. A short press can switch the light mode (slow flash or always on).


星模王



















































































































































































174 1x 175 1x 1x 176

